

Using Ocion Blue In Your Pool or Hot Tub

Natural Water Care

Ocion Blue supports cleaner, clearer pool and spa water by helping control algae and bacteria as part of a balanced water care routine. It helps maintain stable, comfortable water conditions within your overall system.

Step 1: Balance Your Water

Before adding Ocion Blue, ensure your water is properly balanced:

- ✓ **pH:** 7.2–7.6
- ✓ **Total alkalinity:** 50–150 ppm
- ✓ **Calcium Hardness:** 100–350 ppm

Balanced water helps support water clarity, comfort, and overall system performance. You can adjust these levels yourself, or have a professional test your water and ensure it meets the ranges above.

Note: If you are experiencing issues with unwanted metals (i.e. iron, manganese) or phosphates, treat and correct these before adding Ocion Blue. Do not use stain & scale or metal sequestrant products while using Ocion Blue.

Step 2: Add Ocion Blue

Starting Fresh (New Water)

If you are starting fresh:

- ✓ Add chlorine until levels reach 0.5 ppm (do not exceed 1.0 ppm)
- ✓ Use the Ocion Blue app to calculate your exact dose
- ✓ Add Ocion Blue directly to the water

Adding from an Existing Water System

If you are starting with an existing system (chlorine or bromine):

- ✓ Allow chlorine or bromine levels to decrease to 0.5–1.0 ppm
- ✓ Do not exceed 1.0 ppm chlorine while using Ocion Blue
- ✓ Use the Ocion Blue app to calculate your exact dose
- ✓ Add Ocion Blue once levels are within range

Calculate Your
Exact Dose Instantly



Scan QR code to
download the app

Transitioning from Enzymes

If you are using enzyme-based or alternative water treatments:

- ✓ Allow previous products to fully dissipate before use
- ✓ Avoid mixing unknown or unregulated products

Once cleared:

- ✓ Ensure chlorine is within 0.5–1.0 ppm
- ✓ Use the Ocion Blue app to calculate your exact dose
- ✓ Add Ocion Blue directly to the water

Step 3: Maintain Clear, Balanced Water

Routine Maintenance

Maintenance frequency depends on:

- ✓ Frequency of use
- ✓ Number of users
- ✓ Environmental conditions

Testing & Water Balance

- ✓ Use Ocion Blue copper test strips or the 2-part test kit to regularly monitor your water
- ✓ Maintain copper levels between 0.7–1.0 ppm
- ✓ Keep monitoring pH, total alkalinity, and chlorine levels



Your Natural Support for Cleaner and Clearer Water



Connect With Us

604-270-2639

info@ocion.com

www.ocionblue.com